

ADDENDUM - TILLER LEADS

The most common errors in running the control lines to the tiller are mounting the tiller adapter too close to the rudder post, and having the blocks too far aft.

The guidelines shown below in the sketch should be followed. The tiller adapter should be 20"-30" from the rudder post - the closer to 30", the greater the leverage applied. When the tiller is 15° off the boat centerline, the blocks should be placed so the control lines are at a right angle (90°) to the tiller.

